

01 X1 Screen Clicker

English Guide · Product & Quick Start



This product is a multi-port auto clicker that supports independent settings for each click head, random clicking, sequential clicking, and high-speed clicking.

Suitable for a wide range of applications, including automation, testing, and entertainment.

6 Ports
Multi heads

3 Modes
Choose mode

Per-Port
Time/Count

1

Connect
heads

2

Hold
power

3

Select port

4

Set time
/count

5

Start



Power / Pause

Hold to power on/off; press to start or pause.

Switch

Press to select a port; hold to switch time/count.

+ / -

Adjust value; hold for fast adjustment.

Random / Sequential

Enter Random Click or Sequential Click mode.

Display: numbers show time/count; 1-6 = ports; battery icon shows power.

Speed Mode

Fixed-frequency clicking



1s / 5 clicks

Switch Tapping Head → Set Time → Set Number of Taps

Fastest: 99 taps per second
Slowest: 1 tap every 999 minutes

Random Mode

Random within set time



9s / 5 clicks

Complete the set number of taps randomly within the specified time.

Example: 5 taps in 9 seconds. The system will randomly distribute the 5 taps and complete them within 9 seconds.

Sequential Mode

1→6 loop clicking



Per-Port Setup

Set the tap speed and duration for each tap head as needed. After setup, the tap heads will operate in sequence from Head 1 to Head 6.

Disable a port: Set it to 0 sec / 0 taps (Sequential Mode only)

.Example: If only Heads 1-3 are needed for the sequential loop, set Heads 4-6 to 0 sec / 0 taps. The device will then continuously cycle through Heads 1-3.

Port 1

1.0s

10x

Port 2

2.0s

20x

Port 3

3.0s

15x

Port 4

0s

0x

Port 5

0s

0x

Port 6

0s

0x

Reset: press Power 5 times while on.

Do not disassemble; keep charged; avoid overload.